

P O T Z | high tech
watch
winders




GENESIS
Watch Winder

Quick Start Guide

Top keyboard of the device


Press the central button on the top keyboard to **open/close** the front cover of the device.

Press and hold the central button **for 3 seconds** to turn the **device on/off**




Main screen of the device

- 1 Current time
- 2 Operating mode (MANUAL / AUTO / TURBO)
- 3 Set number of revolutions per day
- 4 Case operation status
- 5 Turning the case on/off
- 6 Settings menu: case operation parameters / backlight / pin lock / time
- 7 Parameters for the right case (disabled)




Case operation settings screen

- 1 Operation parameters can be set for each case by clicking on the settings area of the selected case
- 2 Select the operating mode: **auto** / **turbo** / **manual**
- 3 Press the **+** / **-** icons to modify the number of revolutions per day
- 4 Select the direction of rotation of the case:
left / **in both directions** / **right**
- 5 You can enable the range of hours during which the device is to take a break from operation (Sleeping Mode)



Modes



Before making settings for individual watches, please check the operating parameters of the watch winder in the watch manufacturer's instructions.

1 Auto - a mode designed for most automatic watches, in this mode the watch winder makes 650 revolutions per day. You can set the winding direction in it - left, right or alternately in both directions.

2 Turbo - a mode designed to quickly wind up your watch. In this mode, the watch winder performs the maximum number of rotations (10 rpm) during the set time.

In this mode you can set:


- winding direction - left, right or alternately in both directions
- working time in this mode



3 Manual - mode designed for own configuration of settings.

In this mode you can freely set:


- number of revolutions per day
- winding direction - left, right or alternately in both directions
- sleep time (time in which the watch winder does not work, e.g. at night)

Time setting screen


In the bottom menu select the  icon.

Set the current time by clicking the   icons located in the hour and minute area

- 1 You can change the time display mode between **AM/PM** or **24 h**.



Top keyboard of the device




In the bottom menu select the  icon

Click the top switch to activate the front cover open lock screen


Set the 2-5 digit pin code by pressing the corresponding buttons on the upper keyboard

After setting the pin code, the device will require you to enter the pin code before each opening the front cover

The screen also allows you to change the pin code or disable it



Backlight settings screen



The screen allows you to preview and change the color and intensity of the backlight for each of the cases and the base of the device.

Press the icon symbolizing the case or device base to change the backlight parameters


Change the backlight for the selected case

- 1 Press the highlight color to change it to one of the predefined colors

Press the   icons to modify the backlight intensity

Choose one of the backlight modes:

- **Always**
- **When one of the cases is in operation**
- **When the selected case is in operation**
- **Turn off**



P O T Z | high tech
watch
winders

M: info@potz.tech

W: www.potz.tech